



hanging hessian wallcovering

This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 750003.

Occasional imperfections in yarn and weave are a natural characteristic of textile wallcoverings

- | Prepare the wall surface such that it is normally absorbent.
- | Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- | Cut and mark individual drop lengths in sequence as taken from the roll.
- | Bench trim the material (Alternatively overlap and trim when hanging).
- | Damp the back of the material and allow to rest for at least 3 minutes.
- | Paste the wall with **Tapetex Pro – 1 adhesive**. (Available from Stereo – contact details below)
- | **Reverse hang the drops in sequence.** Trim at skirting and ceiling. Butt join bench trimmed material or overlap and trim if not previously trimmed.
- | Do not get adhesive onto the face of the wallcovering as it cannot be wiped off.
- | After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice.

STEREO
5 Bells Yew Green Business Centre, TN3 9BJ
Telephone: 01892 750003

stereo@stereointeriors.co.uk