



hanging glendale textile wallcovering

This product should be hung by a specialist paper hanger with experience of regularly hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 750003.

Occasional imperfections in yarn and weave are a natural characteristic of textile wallcoverings. Variations in tone can also appear within the roll and from roll to roll

- | Prepare the wall surface such that it is normally absorbent.
- | Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- | Pattern repeat. Vertical – 50cm. Horizontal – 68cm.
- | Straight hang.
- | Starting with highest numbered roll, cut and mark individual drop lengths in sequence as taken from the roll.
- | Paste the wall generously with **Tapetex Pro – 1 adhesive**. (Available from Stereo – contact details below)
- | Hang the drops in sequence. Trim at skirting and ceiling. Butt join and pattern match the seams taking care not to overwork them.
- | Use rubber roller or soft brush instead of a hard spatula to firm.
- | Do not to get adhesive onto the face of the wallcovering as it cannot be wiped off.
- | After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice.

STEREO
5 Bells Yew Green Business Centre, TN3 9BJ
Telephone: 01892 750003

stereo@stereointeriors.co.uk